


CompleteView Guide: Exporting Video to CD/DVD

Step 1:

Insert your blank media into your CD-RW or DVD-RW drive. A window should pop up and ask you what you want to do with the media, select option to “burn files to disk using windows.”

From within CompleteView Client Application select playback. Once you have found the clip you want to export, select export. Once you see the screen below, select “export video to file on disk.”




Step 2:

Name the file, and save it to your CD/DVD RW drive.

Step 3:

A text balloon will pop up in the lower right corner of your screen if you have a disk in the drive ready to burn, stating files are ready to be burned. Click that balloon and a box will open. Along the top it will say ‘You have files waiting to be burned to disc.’



Step 4:

Click the balloon and a box will open showing the files sent to the optical disc. Select burn to disc and the burn will begin.

