


# Salient CompleteView VMS Integration to Keep



## FUNCTIONALITY



Camera icon associated with access control event


Alarm priority color bar with text of alarm event

Camera time-date stamp

Scrubber video bar

Set length of video clip with pre and post-alarm timeframes

Play, rewind & fast-forward clip



Export clip and/or single image to send to others

Digital zoom in/out or in multiple directions



- Acknowledged alarm with associated cardholder image
- Ability to create pre-determined acknowledgement instructions and acknowledged comments
- Add still image from video clip

- Cameras – Imported from CompleteView, cameras can be assigned to specific hardware devices and easily accessed upon alarm.
- Views – Create customized multi-camera layouts to link live or recorded views within the video player. Choose from 1x5, 2x2 or 3x3 grids from any associated VMS listed.

- Multi-view allows different cameras from separate locations.
- Any associated video alarm on live monitoring or event history will show camera icon. Alarms can have more than one camera view.
- Video Clips – Configure pre-alarm/post-alarm settings to determine length of clip.
- Acknowledge – Video alarms can have pre-determined acknowledgement requirements for the administrator.

- Attach image to alarm acknowledgement to assist with investigations.
- All alarm acknowledgements are stored in audit archives.
- Place camera icons on maps for easy access.